

XY Series presets list

Please see the "Installation manual" for details of installation and connection.
 Depending on the installation environment, change the settings of Delay and EQ, etc.
 Preset file of M Series with DSP for subwoofer is not prepared.

Combination	Installation Condition	Preset file (.pam)		
		For Full-Range	For Subwoofer	
		Upper side : For K Series with DSP	Only For K Series with DSP	
		Lower side: For M Series with DSP		
XY-81	Single-Use	KDSP_XY-81_V1.0	-	
		MHDSP_XY-81_V1.0		
XY-101	Single-Use	KDSP_XY-101_V1.0	-	
		MHDSP_XY-101_V1.0		
XY-122	Single-Use	KDSP_XY-122_V1.0	-	
		MHDSP_XY-122_V1.0		
XY-152	Single-Use	KDSP_XY-152_V1.0	-	
		MHDSP_XY-152_V1.0		
XY-115S	Single-Use	-	KDSP_XY-115S_V1.0	
XY-118S	Single-Use	-	KDSP_XY-118S_V1.0	
XY-215S	Single-Use	-	KDSP_XY-215S_V1.0	
XY-218S	Single-Use	-	KDSP_XY-218S_V1.0	
XY-218HS	Single-Use	-	KDSP_XY-218HS_V1.0	
XY-81	XY-115S	XY-81 is pole-mounted on XY-115S.	KDSP_XY-81_for_XY-115S_V1.0	KDSP_XY-115S_for_XY-81_V1.0
	XY-118S	XY-81 is pole-mounted on XY-118S.	KDSP_XY-81_for_XY-118S_V1.0	KDSP_XY-118S_for_XY-81_V1.1
	XY-215S	XY-81 is pole-mounted on XY-215S.	KDSP_XY-81_for_XY-215S_V1.0	KDSP_XY-215S_for_XY-81_V1.0
XY-101	XY-115S	XY-101 is pole-mounted on XY-115S.	KDSP_XY-101_for_XY-115S_V1.0	KDSP_XY-115S_for_XY-101_V1.0
	XY-118S	XY-101 is pole-mounted on XY-118S.	KDSP_XY-101_for_XY-118S_V1.0	KDSP_XY-118S_for_XY-101_V1.1
	XY-215S	XY-101 is pole-mounted on XY-215S.	KDSP_XY-101_for_XY-215S_V1.0	KDSP_XY-215S_for_XY-101_V1.0

XY Series presets list

Please see the "Installation manual" for details of installation and connection.
 Depending on the installation environment, change the settings of Delay and EQ, etc.
 Preset file of M Series with DSP for subwoofer is not prepared.

Combination	Installation Condition	Preset file (.pam)		
		For Full-Range	For Subwoofer	
		Upper side : For K Series with DSP	Only For K Series with DSP	
		Lower side: For M Series with DSP		
XY-122	XY-115S	XY-122 is pole-mounted on XY-115S.	KDSP_XY-122_for_XY-115S_V1.0 MHDSP_XY-122_for_XY-115S_V1.0	KDSP_XY-115S_for_XY-122_V1.0
	XY-118S	XY-122 is pole-mounted on XY-118S.	KDSP_XY-122_for_XY-118S_V1.0 MHDSP_XY-122_for_XY-118S_V1.0	KDSP_XY-118S_for_XY-122_V1.1
	XY-215S	XY-122 is pole-mounted on XY-215S.	KDSP_XY-122_for_XY-215S_V1.0 MHDSP_XY-122_for_XY-215S_V1.0	KDSP_XY-215S_for_XY-122_V1.0
	XY-215S & XY-218HS	XY-122 is pole-mounted on XY-215S XY-218HS is stacked between 2 units of XY-122 & XY-215S.	KDSP_XY-122_for_XY-215S_XY-218HS_V1.0 MHDSP_XY-122_for_XY-215S_XY-218HS_V1.0	KDSP_XY-215S_for_XY-122_XY-218HS_V1.0 KDSP_XY-218HS_for_XY-122_XY-215S_V1.0
	XY-218S	XY-122 is pole-mounted with speaker-stand. XY-218S is stacked between 2 units of XY-122.	KDSP_XY-122_for_XY-218S_V1.0 MHDSP_XY-122_for_XY-218S_V1.0	KDSP_XY-218S_for_XY-122_V1.1
	XY-218HS	XY-122 is mounted on XY-218HS installed vertically.	KDSP_XY-122_for_XY-218HS_V1.0 MHDSP_XY-122_for_XY-218HS_V1.0	KDSP_XY-218HS_for_XY-122_V1.0
XY-152	XY-118S	XY-152 is pole-mounted on XY-118S.	KDSP_XY-152_for_XY-118S_V1.0 MHDSP_XY-152_for_XY-118S_V1.0	KDSP_XY-118S_for_XY-152_V1.1
	XY-215S	XY-152 is pole-mounted on XY-215S.	KDSP_XY-152_for_XY-215S_V1.0 MHDSP_XY-152_for_XY-215S_V1.0	KDSP_XY-215S_for_XY-152_V1.0
	XY-218S	XY-152 is pole-mounted with speaker-stand. XY-218S is stacked between 2 units of XY-122.	KDSP_XY-152_for_XY-115S_V1.0 MHDSP_XY-152_for_XY-115S_V1.0	KDSP_XY-218S_for_XY-152_V1.1
	XY-218HS	XY-152 is mounted on XY-218HS installed vertically.	KDSP_XY-152_for_XY-218HS_V1.0 MHDSP_XY-152_for_XY-218HS_V1.0	KDSP_XY-218HS_for_XY-152_V1.0